


We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this pendant fixture. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

The manufacturer warrants this lighting fixture against defects in materials and workmanship for a period of five year(s) from the date of purchase. If within this period the product is found to be defective in material or workmanship, the product must be returned, with a copy of the bill of sale as proof of purchase, to the original place of purchase. The manufacturer will, at its option, repair, replace, or refund the purchase price to the original purchaser or consumer. This warranty does not cover light bulbs or the fixture becoming damaged due to misuse, accidental damage, improper handling and/or installation, and specifically excludes liability for direct, incidental, or consequential damages. Some states do not allow exclusions or limitations on an implied warranty, so the above exclusions and limitations may not apply. This warranty gives you specific rights and you may also have other rights that vary from state to state.

Retain this manual for future use.

- ❑ Read all instructions prior to beginning the installation process.
- ❑ Make sure the power is turned off at the electrical panel box before beginning your installation. Turning the power off at the wall switch is not sufficient to prevent electrical shock.
- ❑ This fixture is intended to be mounted to a 4 in. square x 2-1/8 in. deep metal octagon outlet box. The box must be directly supported by the building structure.
- ❑ All electrical connections must be in accordance with local codes and the National Electrical Code. If you are unfamiliar with methods of installing electrical wiring, secure the services of a qualified licensed electrician.

 **CAUTION:** Keep the lamp away from materials that may burn.

- ❑ To clean the fixture, first disconnect the power to the fixture by turning off the circuit breaker or by removing the fuse at the fuse box.
- ❑ Use a dry or slightly dampened, clean cloth (use clean water, never use a solvent) to wipe the interior and exterior surfaces of the fixture.
- ❑ Allow the fixture to dry completely before power is restored.

This diagram illustrates the exploded view of a metal safe assembly. The components are labeled as follows:

- A:** The top horizontal plate of the safe.
- B:** The main vertical body of the safe.
- C:** The bottom horizontal plate of the safe.
- D:** The handle assembly, including the handle and the mounting bracket.
- E:** The locking mechanism, including the lock cylinder and the mounting bracket.
- F:** The decorative front panel with a lattice pattern.
- G:** The main body of the safe, showing the internal compartment and the door.
- H:** The base plate of the safe.

Part	Description	Quantity
A	Canopy	1
B	Long straight rod (12 in.)	2
C	Short straight rod (6 in.)	1
D	Threaded rod assembly (6.1 in.)	1
E	Straight rod assembly (6 in.)	1
F	Decorative frame	1
G	Fabric shade assembly	1
H	Diffuser	1

AA
Outlet box screws
x 2

BB
Wire connectors
x 3

CC
Mounting bracket
assembly
x 1

DD
Decorative nut
x 2

EE
Diffuser nut
x 1

Diagram illustrating a cable assembly with labels BB and CC.

A diagram of a door handle mechanism. A light bulb is mounted on a vertical shaft. A handle is attached to the shaft. The handle is labeled 'G' and the light bulb is labeled 'E'. The handle is shown in a position where it is being turned, with an arrow indicating the direction of rotation.

Fig. 1. A schematic diagram of a mechanical device for processing a material. It shows a vertical shaft with a central pulley and a horizontal frame with a lattice structure. A motor is connected to the shaft via a belt drive. The device is mounted on a base with a rotating platform.

Problem	Possible Cause	Solution
The light bulb will not illuminate.	The light bulb is burned out.	Replace the light bulb.
	The power is off.	Make sure the power supply is on.
	There is a faulty wire connection.	Check the wiring. Contact a qualified and licensed electrician if you are not comfortable troubleshooting wiring problems.
	There is a faulty switch.	Test or replace the switch.
The fuse blows or the circuit breaker trips when the light bulb is illuminated.	There are crossed wires, or the power wire is not properly grounded.	Check the wire connections.